

I'm not a bot





Orbit 24713 Timer User Manual and Guide The Orbit 24713 Timer user manual and guide are available online for free viewing or downloading in PDF format. The database contains one manual, which is the operation and user's manual. Important Information for Winterizing the Timer When expecting freezing temperatures, it's essential to remove the timer from the hose faucet and store it indoors to prevent potential freeze damage. A filter is also provided to prolong the life of the timer by trapping dirt particles. Regularly clean and replace the filter if worn out. Timer Features and Programming The Orbit 24713 Timer features a dial for customizing the watering schedule, +/- buttons for adjusting time and programming, and an ARROW button for navigating during programming. Additionally, it has a STATION button for moving between Station 1 and Station 2, and MANUAL/CLEAR and RESET buttons for manual operation or resetting to factory settings. Programming Instructions To program the timer, turn the dial to SET CLOCK, set the time of day using the +/- buttons, press the ARROW button to set the current day, select the day of the week with the +/- buttons, toggle back to the time of day by pressing the ARROW button, and save changes by turning the dial. Battery Installation and Replacement Insert two AA (1.5V) alkaline batteries into the tray on the back of the timer, firmly replace the battery tray for water resistance and increased battery life, and dispose of used or dead batteries properly. Replace batteries when the low battery icon appears on the display. Important Safety Notes Never mix old and new batteries, nor mix alkaline and rechargeable (e.g., nickel-cadmium) batteries. Also, do not operate the timer at temperatures above 120°F or below freezing, and keep it away from fire to avoid potential explosion or leakage of batteries. 1. Set the desired start time by pressing the ARROW button to move through and select a time; A, B, or C. Use the +/- buttons to adjust the time of day, including AM and PM, and hold the button down for faster adjustment. A box will appear around each programmed start time. To remove a start time, press CLEAR. 2. Press the STATION button to move through stations 1 or 2 and toggle them on/off using the +/- buttons. Note that all stations are automatically selected when adding a start time, and pressing the - button toggles a station off. 3. Repeat steps 1-2 to program additional start times. 4. Turn the dial to save changes. Only one start time is required. The Orbit Hose Faucet Timer is a device designed for automating watering schedules. It comes in a model called 24713, manufactured in Vietnam and features a rechargeable Nickel Cadmium battery. The timer can be connected to an outlet via a hose tap connection and has multiple settings for managing water usage. The printer specifications are as follows: Model 24713, made by Orbit, and it requires approval from the manufacturer for any changes. The printed piece must meet designated specifications on this form, which is copyrighted under 2014 Orbit Inc. The timer features a manual/clear filter and has an indicator to show when the battery is low. It also includes additional information such as product coverage, dimensions, and callouts. When using the timer in areas with freezing temperatures, it's recommended to remove it from the hose faucet and store it indoors to prevent damage. The filter should be cleaned regularly and replaced if worn out. The operation manual provides instructions on how to use the +/- buttons to set start times, including AM and PM. It also explains how to move through stations and toggle them on or off. To program additional start times, users can repeat steps 2-5 and turn the dial to save changes. The "HOW LONG" setting allows users to select watering duration from 1 to 360 minutes for each desired station. The timer has a simple design with two dials and multiple buttons for easy navigation. It also features a rain delay press + in auto function, which can be adjusted according to the user's needs.

[Orbit water timer manuals.](#) [Orbit digital water timer instructions.](#) [Orbit 24713 program.](#) [Orbit 24714 instructions.](#) [Orbit 24714 manual.](#) [Orbit digital hose water timer 24713 manual.](#) [Orbit water timer instructions.](#) [Orbit dual water timer instructions.](#) [Orbit timer instructions.](#)